

























ERODIN 2D1S






KÓD	ROZMER			BALÍK	
	2078	360	16/32	1	2/2
002	2078	360	16/32	1	2/2
003	556	362	22	1	1/2
004	1364	482	16	1	1/2
005	376	482	16	1	1/2
006	488	334	16	1	1/2
007	488	290	16	3	1/2
008	488	284	16	1	1/2
014	488	60	16	1	1/2
015	488	60	16	1	1/2
017	1401	507	3	1	1/2
018	619	507	3	1	1/2
019	2078	360	16/32	1	2/2
020	482	170	16	1	1/2
021	432	100	16	1	1/2
022	300	100	16	1	1/2
023	300	100	16	1	1/2
024	488	70	30	2	1/2
026	450	302	3	1	1/2
PRÍSLUŠENSTVO				1	1/2




x2 e1 Ø 7x50mm 	x14 r1 Ø 15x12mm 	x14 r16 	x6 s2 
x32 f1 Ø 8x30mm 	x5 a143 	x5 b119 	x10 s4 
x6 l2 	x1 n260 	x31 p25 Ø 3,5x16mm 	x12 d1 Ø 5x17 mm 
x1 f3 Ø 10x50 mm 	x1 n14 	x1 p17 Ø 6x60 mm 	x4 k1 
x1 L300 	x1 z1 		




POZOR! Nábytok musí byť trvalo pripevnený k stene tak, aby sa zamedzilo riziku prevrátenia. Balík neobsahuje upevňovacie skrutky, pretože typ upevnenia je treba vybrať podľa typu steny. Vyberte typ vhodný pre Vašu stenu. megteieio kotoeieemeket.




1




2




3




4







5






6





7




8



9



10



11

