
























ERODIN 2D1S






KÓD	ROZMĚR				BALÍČEK	
	866	362	22	1		
001	866	362	22	1	1/1	
002	884	360	16/32	1	1/1	
003	884	360	16/32	1	1/1	
004	798	334	16	1	1/1	
005	798	310	16	1	1/1	
006	582	395	16	2	1/1	
008	792	170	16	1	1/1	
009	742	100	16	1	1/1	
010	798	60	16	1	1/1	
011	300	100	16	1	1/1	
012	300	100	16	1	1/1	
013	60	284	16	1	1/1	
015	798	70	30	2	1/1	
016	826	407	3	1	1/1	
017	826	407	3	1	1/1	
018	760	302	3	1	1/1	
PŘISLUŠENSTVÍ					1	1/1













x3 e1 Ø 7x50mm 	x11 r1 Ø 15x12mm 	x11 r16 	x2 s2 
x4 a143 	x4 b119 	x27 f1 Ø 8x30mm 	x28 p25 Ø 3,5x16n 
x6 l2 	x4 d1 Ø 5x17 mm 	x1 n14 	x1 p17 Ø 6x60 mm 
x1 f3 Ø 10x50 mm 	x5 k1 	x1 z1 	
x1 L300 			












POZOR! Nábytek je nutné pevně připevnit ke zdi, abychom se vyhnuli riziku spojenému s jeho převrnutím. Součástí balení nejsou připevňovací šrouby, protože způsoby připevnění je nutné zvolit podle druhu stěny. Vyberte správný pro Váš typ stěny.




1




2




3




4






5






6






7





8




9





10



11



12



13

