

























# ERODIN 2D1S






COD	DIMENSIUNE			PACHET	
	2078	360	16/32	1	2/2
002	2078	360	16/32	1	2/2
003	556	362	22	1	1/2
004	1364	482	16	1	1/2
005	376	482	16	1	1/2
006	488	334	16	1	1/2
007	488	290	16	3	1/2
008	488	284	16	1	1/2
014	488	60	16	1	1/2
015	488	60	16	1	1/2
017	1401	507	3	1	1/2
018	619	507	3	1	1/2
019	2078	360	16/32	1	2/2
020	482	170	16	1	1/2
021	432	100	16	1	1/2
022	300	100	16	1	1/2
023	300	100	16	1	1/2
024	488	70	30	2	1/2
026	450	302	3	1	1/2
<b>ACCESORII</b>				<b>1</b>	<b>1/2</b>




<b>x2</b> <b>e1</b> Ø 7x50mm 	<b>x14</b> <b>r1</b> Ø 15x12mm 	<b>x14</b> <b>r16</b> 	<b>x6</b> <b>s2</b> 
<b>x32</b> <b>f1</b> Ø 8x30mm 	<b>x5</b> <b>a143</b> 	<b>x5</b> <b>b119</b> 	<b>x10</b> <b>s4</b> 
<b>x6</b> <b>l2</b> 	<b>x1</b> <b>n260</b> 	<b>x31</b> <b>p25</b> Ø 3,5x16mm 	<b>x12</b> <b>d1</b> Ø 5x17 mm 
<b>x1</b> <b>f3</b> Ø 10x50 mm 	<b>x1</b> <b>n14</b> 	<b>x1</b> <b>p17</b> Ø 6x60 mm 	<b>x4</b> <b>k1</b> 
<b>x1</b> <b>L300</b> 	<b>x1</b> <b>z1</b> 		




AVERTIZARE! Mobilierul trebuie fixat permanent de perete pentru a evita riscul de răsturnare. Pachetul nu include suruburi de fixare, deoarece tipul de fixare trebuie ales în funcție de tipul de perete. Alege tipul potrivit pentru peretele tău.




# 1




# 2




# 3




# 4







# 5






# 6





# 7




# 8



# 9



# 10



# 11

