
























AIRON 1D1S






KÓD	ROZMER			BALÍK
002	2078	360	16/32	1 / 1/1
003	556	362	22	1 / 1/1
005	375	482	16	1 / 1/1
006	488	334	16	1 / 1/1
007	488	290	16	3 / 1/1
008	488	284	16	1 / 1/1
014	488	60	16	1 / 1/1
015	488	60	16	1 / 1/1
017	1401	507	3	1 / 1/1
018	619	507	3	1 / 1/1
019	2078	360	16/32	1 / 1/1
020	482	173	16	1 / 1/1
021	432	100	16	1 / 1/1
022	300	100	16	1 / 1/1
023	300	100	16	1 / 1/1
024	488	60	30	2 / 1/1
026	450	302	3	1 / 1/1
PRÍSLUŠENSTVO				1 / 1/1

















x6 e1 Ø 7x50mm 	x10 r1 Ø 15x12mm 	x10 r16 	x2 s2 
x32 f1 Ø 8x30mm 	x2 a143 	x2 b119 	x6 s4 
x10 l2 	x2 n260 	x30 p25 Ø 3,5x16mm 	x12 d1 Ø 5x17 mm 
x1 f3 Ø 10x50 mm 	x1 n14 	x1 p17 Ø 6x60 mm 	x4 k1 
x1 L300 	x2 c412.030 	x4 p42 Ø 3,5x25mm 	x1 z1 











POZOR! Nábytok musí byť trvalo pripevnený k stene tak, aby sa zamedzilo riziku prevrátenia. Balík neobsahuje upevňovacie skrutky, pretože typ upevnenia je treba vybrať podľa typu steny. Vyberte typ vhodný pre Vašu stenu.




1




2




3




4







5





6





7




8



9



10



11

