





# AIRON 4D1S 50















Ø10






KÓD	DIMENZIÓ				CSOMAG
002	1401	408	3	2	3/3
003	619	408	3	2	3/3
007	798	60	16	1	1/3
008	798	474	16	1	1/3
009	798	424	16	1	1/3
010	798	60	16	1	1/3
011	375	395	16	2	2/3
015	60	434	16	1	1/3
016	1364	395	16	2	2/3
023	2078	500	16/32	1	3/3
024	2078	500	16/32	1	3/3
025	866	502	22	1	1/3
032	793			1	1/3
033	792	173	16	1	1/3
034	742	100	16	1	1/3
035	450	100	16	1	1/3
036	450	100	16	1	1/3
037	798	60	30	2	1/3
038	760	452	3	1	1/3
<b>KIEGÉSZÍTŐK</b>					1 / 1/3









<b>x6</b> <b>e1</b> Ø 7x50mm 	<b>x12</b> <b>r1</b> Ø 15x12mm 	<b>x12</b> <b>r16</b> 	<b>x2</b> <b>s2</b> 
<b>x34</b> <b>f1</b> Ø 8x30mm 	<b>x10</b> <b>a143</b> 	<b>x10</b> <b>b119</b> 	<b>x50</b> <b>p25</b> Ø 3,5x16mm 
<b>x2</b> <b>n301</b> 	<b>x10</b> <b>l2</b> 	<b>x2</b> <b>n260</b> 	<b>x5</b> <b>k1</b> 
<b>x1</b> <b>f3</b> Ø 10x50 mm 	<b>x1</b> <b>n14</b> 	<b>x1</b> <b>p17</b> Ø 6x60 mm 	<b>x1</b> <b>z1</b> 
<b>x1</b> <b>L450</b> 	<b>x6</b> <b>c412.030</b> 	<b>x12</b> <b>p42</b> Ø 3,5x25mm 	








FIGYELEM! Rögzítse a bútorokat a falhoz, hogy elkerülje a bútor felborulásának kockázatát. A készletben nem találhatóak rögzítőcsavarok, mivel a rögzítés típusa a fal típusától függ. Válassza ki a fal típusának megfelelő kötőelemeket.




# 1




# 2




# 3




# 4




# 5




# 6




# 7




# 8




# 9



# 10



# 11



# 12

