













KAROS RTV 2D1S









 46x f1 Ø8x30	 4x a143	 4x b119	 2x s2
 18x r1 15x12	 1x lb-300	 6x k1	 1x z1
 18x r16 Ø5x24	 28x p25 Ø3.5x16	 1x p9	
 6x e1 Ø7x50	 8x l2	 1x c411.058	

KÓD BROJ KODA COD	ROZMER/ROZMĚR/DIMENZIÓ DIMENZIJA/DIMENZIJE/DIMENSIUNE				BALÍK BALÍČEK CSOMAG PAKET PACHET
001	1500	364	22	1	1/1
002	1428	334	16	1	1/1
003	632	312	16	1	1/1
004	472	360	16/32	1	1/1
005	472	360	16/32	1	1/1
006	359	386	16	1	1/1
007	359	386	16	1	1/1
008	396	313	16	1	1/1
009	396	313	16	1	1/1
010	1428	70	16	1	1/1
011	1428	60	16	2	1/1
012	575	120	16	1	1/1
013	300	120	16	1	1/1
014	300	120	16	1	1/1
016	645	170	16	1	1/1
017	1445	415	2,5	1	1/1
018	302	593	2,5	1	1/1
PRÍSLUŠENSTVO/PŘÍSLUŠENSTVÍ KIEGÉSZÍTŐK/PRIBOR DODATKI/ACCESORII				1	1/1




4

p25	r16	r1	f1	lb-300	b119	k1
x6	x8	x8	x12	x1	x4	x4




5




6


e1
x4




7




8




9





10





11





12




13



14



15



16

