

# AYLA 6808L- Montážny návod

Stojan	Piesty	Mechanizmus																				
Opierka	Sedadlo	Zadná strana																				
<p>(7)</p> <table border="0"> <tr> <td>1.</td> <td></td> <td>X1</td> <td>5MM</td> </tr> <tr> <td>2.</td> <td></td> <td>X8</td> <td>(6X25)MM</td> </tr> <tr> <td>3.</td> <td></td> <td>X4</td> <td>(6X16)MM</td> </tr> <tr> <td>4.</td> <td></td> <td>X8</td> <td></td> </tr> <tr> <td>5.</td> <td></td> <td>X5</td> <td></td> </tr> </table>			1.		X1	5MM	2.		X8	(6X25)MM	3.		X4	(6X16)MM	4.		X8		5.		X5	
1.		X1	5MM																			
2.		X8	(6X25)MM																			
3.		X4	(6X16)MM																			
4.		X8																				
5.		X5																				

  

### 1

### 2

### 3

### 4

### 5

### 6