






LUCAS - POSTEL' - montážny návod B1054



180x200




Súčiastky


A	 M6x90mm	18	E		02
B	 M6	18	F	 Φ4mm	01
C	 Ø8x30mm	38	G	 Φ7x60mm	03
D	 Ø4x30mm	34	H		01


Krok 1




E		02
C	 Ø6x30mm	04

Krok 2




A	 M6x90mm	06
B	 M6	18
C	 Ø8x30mm	16
H		01



Krok 3





A	 M6x90mm	04
B	 M6	04
C	 Ø8x30mm	14
H		01

Krok 4




A		08
B		08
C		04

D		04
G		03



Krok 5



D		30
---	---	----