


1

Szerelési útmutató
Bali DC-1528



2



A		1	B		1	C		1	D		4
E		1	F		1						