





























ROZALI MB-1938




A		M6X30	x10
B		M6X55	x22
C		M8X15	x4
D		M8X70	x4
F			x22
G			x4
H			x4
I			x32
J			x4
K		M4	x1
L		M5	x1
M			x1




1  x2	2  x2	3  x2	4  x2
5a  x2	5b  x2	6  x2	7  x1
8  x16	9a  x1	9b  x1	10a  x1
10b  x1	11  x5		


1.




2.




3.



4.



5.



6.

